

BeagleBone

This is a page about TI's Cortex-A8 based; BeagleBone.

- [Availability](#)
- [Basic Requirements](#)
- [ARM Cross Compiler: GCC](#)
- [Bootloader: U-Boot](#)
- [Linux Kernel](#)
 - [Mainline](#)
 - [TI BSP](#)
- [Root File System](#)
 - [Debian 10](#)
 - [Ubuntu 20.04 LTS](#)
- [Setup microSD card](#)
- [Install Kernel and Root File System](#)
 - [Copy Root File System](#)
 - [Set uname_r in /boot/uEnv.txt](#)
 - [Copy Kernel Image](#)
 - [Copy Kernel Device Tree Binaries](#)
 - [Copy Kernel Modules](#)
 - [File Systems Table \(/etc/fstab\)](#)
 - [Networking](#)
 - [Networking: Using a shared SD card with Multiple BeagleBone](#)
 - [Remove microSD/SD card](#)
 - [U-Boot Overlays](#)
- [Comments](#)

Availability

Boards:

[BeagleBone](#) at Digi-Key

Basic Requirements

- Running a recent supported release of Debian, Fedora or Ubuntu on a x86 64bit based PC; without OS Virtualization Software.
- Many of the listed commands assume /bin/bash as the default shell.
- ARM Cross Compiler – Linaro: <https://www.linaro.org>
 - Linaro Toolchain Binaries: <https://www.linaro.org/downloads/>
- Bootloader
 - Das U-Boot – the Universal Boot Loader: <http://www.denx.de/wiki/U-Boot>
 - Source: <https://github.com/u-boot/u-boot/>
- Linux Kernel
 - Linus's Mainline tree: <https://git.kernel.org/pub/scm/linux/kernel/git/torvalds/linux.git>
- ARM based rootfs
 - Debian: <https://www.debian.org>
 - Ubuntu: <https://www.ubuntu.com>

ARM Cross Compiler: GCC

This is a pre-built (64bit) version of GCC that runs on generic linux, sorry (32bit) x86 users, it's time to upgrade...

Download/Extract:

```
user@localhost:~$
```

```
wget -c https://releases.linaro.org/components/toolchain/binaries/6.5-2018.12/arm-linux-gnueabi/gcc-linaro-6.5.0-2018.12-x86_64_arm-linux-gnueabi.tar.xz
tar xf gcc-linaro-6.5.0-2018.12-x86_64_arm-linux-gnueabi.tar.xz
export CC=`pwd`/gcc-linaro-6.5.0-2018.12-x86_64_arm-linux-gnueabi/bin/arm-linux-gnueabi-
```

Test Cross Compiler:

```
user@localhost:~$
```

```
${CC}gcc --version
```

Test Output:

```
arm-linux-gnueabi-hf-gcc (Linaro GCC 6.5-2018.12) 6.5.0
Copyright (C) 2017 Free Software Foundation, Inc.
This is free software; see the source for copying conditions. There is NO
warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.
```

Bootloader: U-Boot

Das U-Boot – the Universal Boot Loader: <http://www.denx.de/wiki/U-Boot>
eewiki.net patch archive: <https://github.com/eewiki/u-boot-patches>
Download:

```
user@localhost:~$
```

```
git clone -b v2019.04 https://github.com/u-boot/u-boot --depth=1
cd u-boot/
```

Patches:

```
user@localhost:~/u-boot$
```

```
wget -c https://github.com/eewiki/u-boot-patches/raw/master/v2019.04/0001-am335x_ewm-uEnv.txt-bootz-n-fixes.
patch
wget -c https://github.com/eewiki/u-boot-patches/raw/master/v2019.04/0002-U-Boot-BeagleBone-Cape-Manager.patch

patch -p1 < 0001-am335x_ewm-uEnv.txt-bootz-n-fixes.patch
patch -p1 < 0002-U-Boot-BeagleBone-Cape-Manager.patch
```

Configure and Build:

```
user@localhost:~/u-boot$
```

```
make ARCH=arm CROSS_COMPILE=${CC} distclean
make ARCH=arm CROSS_COMPILE=${CC} am335x_ewm_defconfig
make ARCH=arm CROSS_COMPILE=${CC}
```

Linux Kernel

This script will build the kernel, modules, device tree binaries and copy them to the deploy directory.

Mainline

Download:

```
~/
```

```
git clone https://github.com/RobertCNelson/bb-kernel
cd bb-kernel/
```

For am33x-v4.14 (Longterm 4.14.x):

```
user@localhost:~/bb-kernel$
```

```
git checkout origin/am33x-v4.14 -b tmp
```

For am33x-rt-v4.14 (Longterm 4.14.x + Real-Time Linux):

```
user@localhost:~/bb-kernel$
```

```
git checkout origin/am33x-rt-v4.14 -b tmp
```

For am33x-v4.19 (Longterm 4.19.x):

```
user@localhost:~/bb-kernel$
```

```
git checkout origin/am33x-v4.19 -b tmp
```

For am33x-rt-v4.19 (Longterm 4.19.x + Real-Time Linux):

```
user@localhost:~/bb-kernel$
```

```
git checkout origin/am33x-rt-v4.19 -b tmp
```

For am33x-v5.4 (Longterm 5.4.x):

```
user@localhost:~/bb-kernel$
```

```
git checkout origin/am33x-v5.4 -b tmp
```

For am33x-rt-v5.4 (Longterm 5.4.x + Real-Time Linux):

```
user@localhost:~/bb-kernel$
```

```
git checkout origin/am33x-rt-v5.4 -b tmp
```

Build:

```
user@localhost:~/bb-kernel$
```

```
./build_kernel.sh
```

TI BSP

Download:

```
~/
```

```
git clone https://github.com/RobertCNelson/ti-linux-kernel-dev.git  
cd ti-linux-kernel-dev/
```

For TI v4.14.x:

```
~/ti-linux-kernel-dev/
```

```
git checkout origin/ti-linux-4.14.y -b tmp
```

For TI v4.14.x: Real-Time

```
~/ti-linux-kernel-dev/
```

```
git checkout origin/ti-linux-rt-4.14.y -b tmp
```

For TI v4.19.x:

```
~/ti-linux-kernel-dev/
```

```
git checkout origin/ti-linux-4.19.y -b tmp
```

For TI v4.19.x: Real-Time

```
~/ti-linux-kernel-dev/
```

```
git checkout origin/ti-linux-rt-4.19.y -b tmp
```

For TI v5.4.x:

```
~/ti-linux-kernel-dev/
```

```
git checkout origin/ti-linux-5.4.y -b tmp
```

For TI v5.4.x: Real-Time

```
~/ti-linux-kernel-dev/
```

```
git checkout origin/ti-linux-rt-5.4.y -b tmp
```

Build:

```
user@localhost:~/ti-linux-kernel-dev$
```

```
./build_kernel.sh
```

Root File System

Debian 10

User	Password
debian	temppwd
root	root

Download:

```
user@localhost:~$
```

```
wget -c https://rcn-ee.com/rootfs/eewiki/minfs/debian-10.4-minimal-armhf-2020-05-10.tar.xz
```

Verify:

```
user@localhost:~$
```

```
sha256sum debian-10.4-minimal-armhf-2020-05-10.tar.xz
```

```
sha256sum output:
```

```
cd598e42850cbef87602bf15ee343abfbf0d8c6ba81028c741672b5f24263534  debian-10.4-minimal-armhf-2020-05-10.tar.xz
```

Extract:

```
user@localhost:~$
```

```
tar xf debian-10.4-minimal-armhf-2020-05-10.tar.xz
```

Ubuntu 20.04 LTS

User	Password
ubuntu	temppwd

Download:

```
user@localhost:~$
```

```
wget -c https://rcn-ee.com/rootfs/eewiki/minfs/ubuntu-20.04-minimal-armhf-2020-05-10.tar.xz
```

Verify:

```
user@localhost:~$
```

```
sha256sum ubuntu-20.04-minimal-armhf-2020-05-10.tar.xz
```

sha256sum output:

```
de0177ac9259fdbcc626ee239f4258b64070c0921dbc38c45fab6925a5becaa1  ubuntu-20.04-minimal-armhf-2020-05-10.tar.xz
```

Extract:

```
user@localhost:~$
```

```
tar xf ubuntu-20.04-minimal-armhf-2020-05-10.tar.xz
```

Setup microSD card

We need to access the External Drive to be utilized by the target device. Run `lsblk` to help figure out what linux device has been reserved for your External Drive.

Example: for DISK=/dev/sdX

```
lsblk
NAME MAJ:MIN RM  SIZE RO TYPE MOUNTPOINT
sda   8:0    0 465.8G  0 disk
sda1  8:1    0   512M  0 part /boot/efi
sda2  8:2    0 465.3G  0 part /              <- Development Machine Root Partition
sdb   8:16   1   962M  0 disk              <- microSD/USB Storage Device
sdb1  8:17   1   961M  0 part              <- microSD/USB Storage Partition
```

Thus you would use:

```
export DISK=/dev/sdb
```

Example: for DISK=/dev/mmcblkX

```
lsblk
NAME      MAJ:MIN  RM  SIZE RO TYPE MOUNTPOINT
sda       8:0      0 465.8G  0 disk
sda1     8:1      0   512M  0 part /boot/efi
sda2     8:2      0 465.3G  0 part /              <- Development Machine Root Partition
mmcblk0  179:0    0   962M  0 disk              <- microSD/USB Storage Device
mmcblk0p1 179:1    0   961M  0 part              <- microSD/USB Storage Partition
```

Thus you would use:

```
export DISK=/dev/mmcblk0
```

Erase partition table/labels on microSD card:

```
sudo dd if=/dev/zero of=${DISK} bs=1M count=10
```

Install Bootloader:

```
user@localhost:~$
```

```
sudo dd if=./u-boot/MLO of=${DISK} count=1 seek=1 bs=128k
sudo dd if=./u-boot/u-boot.img of=${DISK} count=2 seek=1 bs=384k
```

Create Partition Layout:

With util-linux v2.26, sfdisk was rewritten and is now based on libfdisk.

Check the version of sfdisk installed on your pc

```
sudo sfdisk --version
```

Example Output

```
sfdisk from util-linux 2.27.1
```

sfdisk >= 2.26.x

```
sudo sfdisk ${DISK} <<-__EOF__
4M,,L,*
__EOF__
```

sfdisk <= 2.25.x

```
sudo sfdisk --unit M ${DISK} <<-__EOF__
4,,L,*
__EOF__
```

Format Partition:

```
for: DISK=/dev/mmcblkX
sudo mkfs.ext4 -L rootfs ${DISK}p1

for: DISK=/dev/sdX
sudo mkfs.ext4 -L rootfs ${DISK}1
```

Mount Partition:

On most systems these partitions may be auto-mounted...

```
sudo mkdir -p /media/rootfs/

for: DISK=/dev/mmcblkX
sudo mount ${DISK}p1 /media/rootfs/

for: DISK=/dev/sdX
sudo mount ${DISK}1 /media/rootfs/
```

Install Kernel and Root File System

To help new users, since the kernel version can change on a daily basis. The kernel building scripts listed on this page will now give you a hint of what kernel version was built.

```
-----  
Script Complete  
eeewiki.net: [user@localhost:~$ export kernel_version=5.X.Y-Z]  
-----
```

Copy and paste that "export kernel_version=5.X.Y-Z" exactly as shown in your own build/desktop environment and hit enter to create an environment variable to be used later.

```
export kernel_version=5.X.Y-Z
```

Copy Root File System

```
user@localhost:~$  
  
sudo tar xfvp ./*-*-armhf-*/armhf-rootfs-*.tar -C /media/rootfs/  
sync  
sudo chown root:root /media/rootfs/  
sudo chmod 755 /media/rootfs/
```

Set uname_r in /boot/uEnv.txt

```
user@localhost:~$  
  
sudo sh -c "echo 'uname_r=${kernel_version}' >> /media/rootfs/boot/uEnv.txt"
```

Copy Kernel Image

Kernel Image:

```
user@localhost:~$  
  
sudo cp -v ./bb-kernel/deploy/${kernel_version}.zImage /media/rootfs/boot/vmlinuz-${kernel_version}
```

Copy Kernel Device Tree Binaries

```
user@localhost:~$  
  
sudo mkdir -p /media/rootfs/boot/dtbs/${kernel_version}/  
sudo tar xfv ./bb-kernel/deploy/${kernel_version}-dtbs.tar.gz -C /media/rootfs/boot/dtbs/${kernel_version}/
```

Copy Kernel Modules


```
user@localhost:~$
```

```
sudo tar xfv ./bb-kernel/deploy/${kernel_version}-modules.tar.gz -C /media/rootfs/
```

File Systems Table (/etc/fstab)

```
user@localhost:~$
```

```
sudo sh -c "echo '/dev/mmcbk0p1 / auto errors=remount-ro 0 1' >> /media/rootfs/etc/fstab"
```

Networking

Edit: /etc/network/interfaces

```
sudo nano /media/rootfs/etc/network/interfaces
```

Add:

```
/etc/network/interfaces
```

```
auto lo
iface lo inet loopback

auto eth0
iface eth0 inet dhcp
```

Networking: Using a shared SD card with Multiple BeagleBone

To always enable the Ethernet interface as eth0.

Edit: /etc/udev/rules.d/70-persistent-net.rules

```
sudo nano /media/rootfs/etc/udev/rules.d/70-persistent-net.rules
```

Add:

```
/etc/udev/rules.d/70-persistent-net.rules
```

```
# BeagleBone: net device ()
SUBSYSTEM=="net", ACTION=="add", DRIVERS=="*", ATTR{dev_id}=="0x0", ATTR{type}=="1", KERNEL=="eth*", NAME="eth0"
```

Remove microSD/SD card

```
sync
sudo umount /media/rootfs
```

U-Boot Overlays

Full Documentation: [readme](#)

Any issues:

Any issues run:

```
sudo /opt/scripts/tools/version.sh
```

Enable:

/boot/uEnv.txt

```
enable_uboot_overlays=1
```

To Disable: BB-ADC:

/boot/uEnv.txt

```
disable_uboot_overlay_adc=1
```

U-Boot: override detected capes

/boot/uEnv.txt

```
uboot_overlay_addr0=/lib/firmware/<file0>.dtbo  
uboot_overlay_addr1=/lib/firmware/<file1>.dtbo  
uboot_overlay_addr2=/lib/firmware/<file2>.dtbo  
uboot_overlay_addr3=/lib/firmware/<file3>.dtbo
```

U-Boot: disable auto-loading of detected capes

/boot/uEnv.txt

```
disable_uboot_overlay_addr0=1  
disable_uboot_overlay_addr1=1  
disable_uboot_overlay_addr2=1  
disable_uboot_overlay_addr3=1
```

U-Boot: load 4 more un-detected capes

/boot/uEnv.txt

```
uboot_overlay_addr4=/lib/firmware/<file4>.dtbo  
uboot_overlay_addr5=/lib/firmware/<file5>.dtbo  
uboot_overlay_addr6=/lib/firmware/<file6>.dtbo  
uboot_overlay_addr7=/lib/firmware/<file7>.dtbo
```

U-Boot: PRU Options (v4.14.x-ti)

/boot/uEnv.txt

```
uboot_overlay_pru=/lib/firmware/AM335X-PRU-RPROC-4-14-TI-00A0.dtbo
```

U-Boot: PRU Options (v4.19.x-ti)

/boot/uEnv.txt

```
uboot_overlay_pru=/lib/firmware/AM335X-PRU-RPROC-4-19-TI-00A0.dtbo
```

U-Boot: PRU Options

/boot/uEnv.txt

```
uboot_overlay_pru=/lib/firmware/AM335X-PRU-UIO-00A0.dtbo
```

U-Boot: Cape Universal

/boot/uEnv.txt

```
enable_uboot_cape_universal=1
```

Comments

Any questions or comments please go to our TechForum: [TechForum](#)